

#### **BLANC X6**



## **Description:**

Highly alkaline hygienising detergent, low foaming, with a peracetic acid solution (15%), easy to rinse. It favours the removal, together with dirt, of germs and bacteria. Can be used as a cold terminal hygieniser product for industrial use equipment, drums, pipes, machinery and also objects and surfaces with specific deodorant and bleaching prop-

Particularly suited for CIP systems with automatic injection dispensing systems.

#### **Directions for use:**

- Proceed as follows for washing systems with recirculation and automatic dosing:
  - 1. Rinse the system with water.
  - 2. Wash with a recirculation method with a minimum solution at 0.8% of Blanc X6 in cold water (20-25°C) for at least 5 minutes in terms of application time.
  - **3.**Drain and rinse thoroughly with drinking water.
- To wash tanks, tiled surfaces, floors, etc. with sponges or scrubbers: dilute the product from 1% to 4% (10-40 ml per litre).

CAUTION: Not suitable for use on materials containing copper and on light metal such as aluminum. Always rinse surfaces after use (within 1 hour).

#### Warnings:

To handle the product follow the precautionary advice on the safety data sheet.

## **Technical Features:**

Appearance and colour: Clear liquid

Odour: characteristic

pH: 0,93

Flash point: > 100°C

Relative density: 1,05 g/cm3 Solubility in water: soluble Solubility in oil: partially soluble

### Storage:

Unopened and stored at room temperature away from direct sunlight.

# **Packaging**

**PACKAGING ITEM CODE** JERRY CAN 5 KG 76923 JERRY CAN 25 KG 76924

> FRA-BER s.r.l. Head of the Laboratory

Original signed document available at the company's headquarters. The data contained is the result of technological research of our laboratory and is provided for information purposes only. We exclude any liability arising from an incorrect choice of product and the lack of the necessary precautions, which must always be verified by the user.





