

Description:

RESTORES PLASTIC, DASHBOARDS. RUBBER AND LEATHER.

Polish Plus Aroma is a vanilla-scented detergent specifically designed by the Fra-Ber research and development laboratories for cleaning and protecting internal and external plastic parts such as dashboards, trims, fascias, tyres, bumpers, fenders, mouldings, rubber and leather parts of all transport vehicles (cars, trucks, motorbikes, vans etc.). Its special formula leaves the surfaces smooth to the touch without discolouring or making them greasy, while ensuring an effective antistatic barrier against dust and anti-UV, especially indispensable for the external plastic parts, the dashboards and the plastic parts of doors close to windows, which are often exposed to solar radiation. The vehicle's plastic parts are especially sensitive, in fact the micro pores of their surfaces tend to absorb dust and dirt and, as a consequence, they tend to age prematurely. That is why we recommend using Polish Plus Aroma regularly after thorough cleaning. Fra-Ber produces and packages directly this product in Italy according to the best quality standards.

Directions for use:

1. Use the pure product or dilute it 1:3 (1 part product and 3 parts water) using a Fra-Ber graduated bottle.
2. Fit a Fra-Ber sprayer to the graduated bottle and spray the product evenly 20 cm away from the surface.
3. Spread the product evenly with the aid of a microfibre cloth.
4. Wipe with a dry cloth.

Warnings:

Do not apply on the tread.

To handle the product follow the precautionary advice on the safety data sheet.

For professional and public use.

Technical Features:

Appearance and color: Neutral liquid

Odor: characteristic

pH: 7.0 ± 0.5

Flash point: >100°C

Relative density: 1.00 g/cm³ ± 0,005

Solubility in water: soluble

It also contains among other ingredients: < 5% Non ionic Surfactant, Perfume (COUMARIN), Conservanti (BENZISOTHIAZOLINONE, PHENOXYETHANOL)

Storage:

Unopened and stored at room temperature away from direct sunlight.

Packaging:

PACKAGING	ITEM CODE
JERRY-CAN 4,5 LT	700209
JERRY-CAN 10 LT	74390
JERRY-CAN 25 LT	74391

FRA-BER s.r.l.
Head of the Laboratory

Original signed document available at the company's headquarters. The data contained is the result of technological research of our laboratory and is provided for information purposes only. We exclude any liability arising from an incorrect choice of product and the lack of the necessary precautions, which must always be verified by the user.